How to calibrate in windows 10

Please copy the firmware to any folder except desktop.

①Run "eGalaxCalibration.exe"

🕌 eGalaxDevOp	2022/9/8 9:03	文件夹	
📙 eGalaxUpdateLog	2022/9/8 9:03	文件夹	
📙 Log_5682	2022/9/8 9:03	文件夹	
BETI_DeclarationAndDisclaimer.pdf	2021/7/16 16:19	WPS PDF 文档	478 KB
📄 eGalax. dat	2020/9/2 14:39	DAT 文件	2 KB
🔄 eGalax5960Suite. exe	2021/7/16 16:19	应用程序	2,020 KB
💝 eGalaxBuilder5. exe	2021/7/16 16:19	应用程序	7,025 KB
📄 eGalaxBuilder5.log	2021/7/16 16:38	文本文档	1 KB
🗟 eGalaxCalibration. exe 🧼 Opening	2021/7/16 16:19	应用程序	3,114 KB
aGalaxCalibration. ini	2021/7/16 16:19	配置设置	1 KB
🔄 eGalaxFPCTester. exe	2021/7/16 16:19	应用程序	2,083 KB
aGalaxFPCTester.ini	2021/7/16 16:19	配置设置	1 KB
🔄 eGalaxSensorTester4. exe	2021/7/16 16:19	应用程序	2,475 KB
🔄 eGalaxTestAnalyzer. exe	2021/7/16 16:21	应用程序	2,283 KB
🚰 eGalaxTuner_80HXXX. exe	2021/7/16 16:19	应用程序	2,789 KB
🗿 eGalaxUpdate. ini	2021/7/16 16:19	配置设置	3 KB
📭 eGalaxUpdate2. exe	2021/7/16 16:19	应用程序	4,062 KB
[2] EULA. pdf	2021/7/16 16:19	WPS PDF 文档	192 KB
🚳 HIDdAPI. dll	2021/7/16 16:19	应用程序扩展	2,101 KB
📄 LastTestLog. txt	2021/7/16 16:38	文本文档	1 KB
🔐 OPDraw. exe	2021/7/16 16:19	应用程序	2,578 KB
2 OPDraw. ini	2021/7/16 16:19	配置设置	9 KB
PCAP80H83_5682_v00_HLZ_M01_00_C002_Nanquan_URI_DThqa. H83	2021/7/16 16:19	H83 文件	334 KB
SensorTest_Result.txt	2021/7/16 16:38	文本文档	1 KB
🕘 SensorTestDefault. ini	2021/7/16 16:37	配置设置	4 KB
📗 UniformityTableResult. txt	2021/7/16 16:38	文本文档	1 KB
📄 version. txt	2021/7/16 16:19	文本文档	1 KB

2 Press and hold the red target icon using finger until blue

circle finished to 100%.



EETI - eGalaxCalibration v1.0.4.7

+

Model: Orion_0592_5682 / Version: 00_HLZ_M01

Please put one finger on the target position and wait the beep sound

Upper Left

Last Record[0](2211, 1892)

Last Record[1](14302, 1968)

Last Record[2](2179, 14382)

Last Record[3](14325, 14404)

	EE11 - eGalaxCalibration v1.0.4.7		
	Model: Orien_0592_5682 / Version: 00_HLZ_M01		
Carl Carl	Please put one finger on the target position and wait the beep sound		
	Upper Left		
	Last Record(0)(2211, 1892)		
	Lant Record[1](14302, 1968)		
	Last Record[2](2178, 14362)		
	Last Record[3](14325, 14404)		
	eGalax_eMPIA Technology Inc.	*	

③ Calibration tool will automatically exit if you have done with 4 times press red target icon(top left corner, top right corner, bottom left corner, bottom right corner).